



SERVICE TIPS FOR INSTALLERS

Battery Replacement

As noted in the Service Manual (Chapter 6) for your Indico 100 or CMP 200 /DR generators, CPI recommends that you change the lithium battery on the console CPU board and the generator CPU board at least every 5 years. Refer to the Battery Replacement section of Chapter 6 for instructions on how to prevent the loss of console data when the battery is removed.

Troubleshooting

It is important that the installer take a few minutes and become familiar with Chapter 5, Troubleshooting, prior to handling the installation or servicing the generator. There are a lot of valuable tips here that can reduce your evaluation and troubleshooting time should a problem arise.

Pre-Installation Tips

CPI has provided copies of the pre-installation requirements for both the Indico 100 and CMP 200 / DR generators on our website. We suggest you refer to these prior to ordering your generator and prior to installing the generator in the room.