

Model HD65 SERIES

Antenna Pedestal

FEATURES:

- EL/AZ or X-Y Positioner Configuration
- Rugged Construction
- Supports Solid Reflectors up to 4.5 meters (15 ft)
- High Reliability and Accuracy
- High Torque and Low Backlash
- Rotary Joints & Sliprings for Continuous Azimuth Rotation
- Fast Slew Rates
- Brushless DC Motors
- Supports P-Band through Ka-Band
- PC-based Automated Computer Control with P500 / P600 ACU
- Camera Ready and Compatible
- Optional Acquisition-Aid Antenna
- Optional Compass & Inclinometer
- Optional Fiber-Optic Control Available

A member of the CPI Malibu Division HD series of planocentric drive pedestals, the HD65 is designed to support solid reflectors in the range of 3.0 to 4.5-meters or a FLAPS™ reflector up to 5.5-meters, in winds of 50 MPH. High output torque with low backlash is accomplished with the use of planocentric gearboxes and brushless DC motors. The gearboxes use built-in angular ball bearing construction, which improves the ability to support external loads, increases moment rigidity and maximum allowable moment. The result is increased reliability and a reduction in maintenance. The use of roller bearings throughout the gearbox yields low backlash (less than 1 arc. min.).

For added reliability, the pedestal is designed with servo amplifiers that have protection for over-current, voltage, and temperature. O-ring seals on all panels, allows for positive air pressurization of the pedestal.

The HD65 provides both electronic and mechanical stops and all components are modular, with connectorized sub assemblies for ease of maintenance. Strategically placed and sized access hatches ensure that all pedestal components are easily accessible. Safety switches are implemented to protect the operator. Various slip ring and rotary joint packages are available for integration in the pedestal to allow for continuous travel or for high transmit power applications.



MODEL HD65 WITH 4.3M (14 FT) REFLECTOR

Related Data Sheets

- P500 / P600 Antenna Control Unit
- Conically Scanning Feed
- Local/Remote ACU
- Acquisition-Aid Antenna
- Single Channel Monopulse Feed
- Fiber-Optic Interfaces
- Maximum Range Curves

MODEL HD65 SERIES SPECIFICATIONS

Parameter	Specifications		
	Reflector Diameter (meters)		
Antenna	3.0 (10-ft)	3.6 (12-ft)	4.5 (15-ft)
Operating Frequency ¹	1435-2400 MHz		
Polarization ²	Simultaneous Right Hand and Left Hand Circular		
VSWR	2.0:1 maximum		
Feed Type ³	Conically Scanning or Single Channel Monopulse		
Antenna Gain (minimum)			
1435 MHz	29.5 dBi	31.2 dBi	32.8 dBi
1540 MHz	30.0 dBi	31.8 dBi	33.4 dBi
1710 MHz	31.0 dBi	32.6 dBi	34.3 dBi
1850 MHz	32.7 dBi	33.3 dBi	35.0 dBi
2200 MHz	33.1 dBi	35.0 dBi	36.8 dBi
2400 MHz	33.9 dBi	35.6 dBi	37.5 dBi
Antenna Beamwidth (3 dB) (nominal)			
1435 MHz	4.6°	3.8°	3.1°
1540 MHz	4.3°	3.6°	2.9°
1710 MHz	3.9°	3.2°	2.6°
1850 MHz	3.6°	3.0°	2.4°
2200 MHz	3.0°	2.5°	2.0°
2400 MHz	2.7°	2.3°	1.8°
Sidelobes (nominal)			
G/T @ 10° elevation⁴	22 dBp	22 dBp	24 dBp
1435 MHz	7.5 dB/°K	9.2 dB/°K	11.2 dB/°K
1540 MHz	8.0 dB/°K	9.8 dB/°K	11.8 dB/°K
1710 MHz	9.0 dB/°K	10.7 dB/°K	12.7 dB/°K
1850 MHz	9.7 dB/°K	11.4 dB/°K	13.4 dB/°K
2200 MHz	11.2 dB/°K	12.9 dB/°K	15.0 dB/°K
2400 MHz	12.0 dB/°K	13.7 dB/°K	15.7 dB/°K
Pedestal			
Type	Elevation/Azimuth		
Velocity	≤ 35°/sec	≤ 30°/sec	≤ 30°/sec
Acceleration	≤ 40°/sec ²	≤ 35°/sec ²	≤ 30°/sec ²
Travel ⁵	Azimuth	420° minimum (cable wrap)	
	Elevation	-10° to +190° (mechanical)	
Torque	Continuous	3,600 ft-lbs	
	Peak	7,200 ft-lbs	
Compliance	4.0 x 10 ⁻⁷ radians/ ft-lbs		
Environmental			
Temperature	Operating	-40°C to +52°C	
	Storage	-54°C to +71°C	
Relative Humidity	Up to 100%, including condensation		
Rain	Up to 4 Inches per Hour		
Ice	One-half Inch, Radial		
Wind	Operating	80 km/h / 50 MPH (gusting to 105 km/h / 65 MPH)	
	Stowed	193 km/h / 120 MPH	
Weight	1227 kg / 2700 lbs	1364 kg / 3000 lbs	1591 kg / 3500 lbs
Power Requirements	110-220 VAC, 50-60 Hz, 1Ø		

NOTES:

Subject to change without notice.

- Other frequency bands available upon request.
- Simultaneous orthogonal linear polarizations available.
- Specifications denoted are for conically scanning system.
- G/T specifications are nominal and may vary based upon system configuration.
- Continuous azimuth travel is available through the use of an optional slipping/rotary joint assembly.