

CPI Beverly Microwave Division Compact Pulsed Amplifier (8.75 in/222 mm).



Versatile

Wide band, automatic fault recycle, user-friendly microprocessor-controlled logic with integrated computer interface, digital metering, and quiet operation suitable for laboratory environments.

An integral solid state preamplifier and IEEE interface are included as standard features.

Global Applications

230 VAC operation. Designed to meet International Safety Standard EN61010 and Electromagnetic Compatibility 2004/108/EC.

Easy to Maintain

Modular design and built-in fault diagnostic capability.

Worldwide Support

Backed by more than 50 years of high power experience, CPI's worldwide 24-hour customer support network includes more than 20 regional factory service centers.

FEATURES:

- Rack mount
- Coaxial output
- GPIB remote
- Compact high pulsed power
- Single phase AC power
- Local or remote control
- Wide RF bandwidth

BENEFITS:

- Versatile
- Suitable for lab environments
- Designed for the global market
- Modular design and built-in fault diagnostics for easy maintenance
- Wide RF bandwidth reduces number of required amplifiers

APPLICATIONS:

- Test and measurement systems

CPI S-Band 4.0 kW Compact Pulsed Amplifier: VZS3530J1

Specifications

Frequency range	2.0 to 4.0 GHz
Output power	4000 W (in the majority of the frequency band)
Gain	66 dB min. at rated power (with no RF options) -66 dB min at small signal (with no RF options)
Gain adjustment range	20 dB min
Input VSWR	2.5:1 typical
Output VSWR	2.5:1 typical
Load VSWR	1.5:1 max for full spec compliance. May oscillate with unshielded open due to coupling to input. Should not be tested with connector off.
Pulse width	0.1 to 100 μ s
PRF	50 kHz max
Duty cycle	6% max
Delay	300 ns.typcial 400 ns max
Droop	0.5 dB over 50 μ s
NPR	-10 dBm/MHz beam on 110 dBm/MHz beam off
Primary power	220 – 240 VAC, single phase 47 – 63 Hz
Power consumption	2.0 KVA typical
Filament voltage	Reduction of 10% in standby for extended TWT life
Inrush current	200% max
Ambient temperature	-10°C to +40°C -40°C to +70°C
Relative humidity	95% non-condensing
Altitude	10,000 ft. with standard adiabatic Derating of 2°C/1000 ft. operating 40,000 ft. non-operating
Shock and vibration	As normally encountered in a protected laboratory environment
Cooling	Forced air with integral blower Rear air intake & exhaust 0.10° water max external pressure loss allowable
RF Input connection	Type N female
RF Output connection	Type N female
RF Output monitor	Type N female, -46 dB nominal
Dimensions	19 x 8.72 x 26 in. (483 x 221 x 661 mm) Excluding connectors, fans, handles and exhaust duct
Weight	150 lbs. (68 kg) max
Heat dissipation	=1500 W
Safety	EN61010
Acoustic noise	65 dBA @ 3 ft. from amplifier



Beverly Microwave Division
150 Sohier Road
Beverly, Massachusetts
USA 01915

tel +1 978-922-6000
email BMDMarketing@cpii.com
fax +1 978-922-8914
web www.cpii.com

For more detailed information, please refer to the corresponding CPI technical description if one has been published, or contact CPI. Specifications may change without notice as a result of additional data or product refinement. Please contact CPI before using this information for system design.

©2020 Communications & Power Industries LLC. Company proprietary; use and reproduction is strictly prohibited without written authorization from CPI.
4/20