500 Series Tracking Receiver

Antenna Technologies



Overview

For over 50 years, CPI Antenna Technologies experienced engineering staff has been developing high-precision, economical satellite tracking and control systems. The Model 500 series of tracking receivers provides a high quality, cost effective solution as a beacon receiver for satellite tracking, spectrum display, and Uplink Power Control (UPC) receiver source.

The Receiver is an integrated rack mounted (2RU) chassis that includes:

- Dual touch screen display system with intuitive user interface
- Embedded control and DSP processors
- Digital or analog receiver
- Up to 4 internal block down converters for any frequency band combination from L through Ka
- Ethernet, EIA-232/422 serial ports, and analog tracking signal output
- Internal L-Band test signal generator

The receiver effortlessly connects with CPI antenna control systems through standard Ethernet, while supporting third party systems through a configurable analog tracking output.

A short depth (17" W x 15" D; 432 x 381 mm) 4RU no display chassis is also available. This chassis provides the same performance while providing mounting behind large touch-screen ACUs.

MODELS:

- Model 520A Analog receiver with optional internal BDCs
- Model 550A Digital receiver with spectrum display and optional internal BDCs

FEATURES:

- Extended L-Band 890-2450 MHz
- Single, dual or more (custom) polarization inputs
- Ethernet Connectivity
- Monopulse capability (with optional RF plate)
- HTML5 remote GUI
- Support for single or multi-band down conversion for L/S/C/X/Ku/Ka/Q/V
- Acquire C/No 35 dB-Hz Digital, 40 dB-Hz Analog
- Dynamic range > 90 dB
- Quick-Lock acquisition (<1 second)
- Spectrum Display (Digital)

BENEFITS:

• High performance tracking and acquisition

APPLICATIONS:

- Beacon receiver for satellite tracking
- Uplink Power Control (UPC) receiver source



500 Series Tracking Receiver

Technical Specifications

RF Options								
Options	Band(s)	Input	Frequency - GHz	VSWR	Image Rejection	Stablity		
L1	L	50Ω, Type N	0.89-2.45	2:1	40 dB	± 5kHz		
S1	S	50Ω, Type N	2.0-2.8	1.5:1	40 dB	± 25kHz		
C1	С	50Ω, Type N	3.4-4.2	1.5:1	40 dB	± 15kHz		
C2	С	50Ω, Type N	3.4-4.8	1.5:1	40 dB	± 15kHz		
C3	С	50Ω, Type N	4.0-4.8	1.5:1	40 dB	± 15kHz		
X1	Х	50Ω, Type N	7.25-7.75	1.5:1	40 dB	± 25kHz		
X2	Х	50Ω, Type N	7.6-8.5	1.5:1	40 dB	± 25kHz		
Ku1	Ku	50Ω, Type N	10.7-11.9	1.5:1	40 dB	± 25kHz		
Ku2	Ku	50Ω, Type N	11.8-13.0	1.5:1	40 dB	± 25kHz		
Ku3	Ku	50Ω, Type N	10.7-13.0	1.5:1	40 dB	± 25kHz		
Ka1*	Ka	50Ω, SMA	17.0-18.1	1.5:1	40 dB	± 50kHz		
Ka2*	Ka	50Ω, SMA	18.1-19.2	1.5:1	40 dB	± 50kHz		
Ka3*	Ka	50Ω, SMA	19.2-20.3	1.5:1	40 dB	± 50kHz		
Ka4*	Ka	50Ω, SMA	20.2-21.3	1.5:1	40 dB	± 50kHz		
Ka5*	Ka	50Ω, SMA	21.2-22.3	1.5:1	40 dB	± 50kHz		

Note – some BDC configurations available with external 10 MHz reference input, please consult the factory. *Typically externally mounted down conversion.

Receiver Specifications	Analog (Model 520A)	Digital (Model 550A)	
Standard Input Frequency Range	890-2450 MHz	890-2450 MHz	
Total Input Power Level (no damage)	+10 dBm max	+10 dBm max	
Input Beacon Level Range	0 to -96 dBm	0 to -96 dBm	
Beacon Tuning Step Size	1 kHz	1 kHz	
Predetection Bandwidth	280, 6 kHz	250, 4, 1 kHz	
Signal Strength Linearity Error	+/-2 dB	+/- 2 dB	
C/No for Narrowband Acquisition	40 dB-Hz (6 kHz)	35 dB-Hz (1kHz BW)	
Detection Type	PLL	FFT-Based, No Integration	
Sweep Width	+ / - 40 to +/ - 300 kHz	+/- 16 to +/- 300 KHz	
Acquisition Time	1 sec (6 kHz BW, 120 kHz sweep)	300 ms (4 kHz BW, 150 kHz Span)	

Physical Data								
Dimensions (In.)	3.5H x 19W x 20D	Humidity	95%, non-condensing					
Weight (shipping)	23.5 Lbs (28Lbs)	Data Interfaces	Serial RS-232/RS-422, DB-9					
Power	100 - 240 VAC~, 47-63 Hz, 200VA		Ethernet, RJ45 Front Panel, USB					
Temperature, Operating	0° to 50° C	Track Signal Outputs	Analog and streaming digital					
Temperature, Storage	-20° to +70°C	Track Signal Suspais	(serial or Ethernet)					
		Compliance	FCC, CE, REACH					



Contact us at CustomerCareSAT@cpii.com or call us at +1 770-689-2040

The data should be used for basic information only. Formal, controlled specifications may be obtained from CPI for use in equipment design.



Antenna Technologies

1700 NE Cable Drive Conover, NC USA 28613 +1 770-689-2040 1 888-874-7646 (In North America)

1 619-240-8480 (Outside North America)

CustomerCareSAT@cpii.com www.cpii.com

For more detailed information, please refer to the corresponding CPI technical description if one has been published, or contact CPI. Specifications may change without notice as a result of additional data or product refinement. Please contact CPI before using this information for system design. © 2023 Communications & Power Industries LLC. Company proprietary: use and reproduction is strickly prohibited without written authorization from CPI.

©2023 Communications & Power Industries LLC. Company proprietary: use and reproduction is strictly prohibited without written authorization from CPI.