

9.2m Ka, Q and V-Band Turning Head Antenna

Antenna Technologies



Overview

The CPI Antenna Technologies' large diameter KaTx/QRx/VTx-Band antennas require unique design criteria which we have successfully demonstrated with the 9.2 meter product. Items such as reflector surface accuracy, antenna/feed design, structural antenna stiffness and integrity, thermal effects, anti-icing, monopulse tracking, hub redundant air-conditioning, installation and alignments and hub integration all require special engineering expertise at Ka, Q and V-Band.

We have proven our expertise in the above areas and has earned the position as a preferred antenna system provider and integrator to a number of major satellite broadband companies in the world.

FEATURES:

- Precision Ka/Q/V-Band rated surface reflector on steel back-up structure with counterweight arms
- An elevation over azimuth all-steel antenna structure with high stiffness turntable bearing
- A circular polarized Ka/Q/V-Band cassegrain 4-port Tx/Rx feed assembly with TE21 tracking coupler (monopulse) and feed rain blower
- Brushless servo motor jackscrew drive in elevation
- Dual gear-pinion drives with anti-backlash in azimuth
- Access stairway and large work platform for ease of maintenance
- 9-foot dia. hub with five foot roll up access door
- Housing for up to eight high power amplifiers (HPA's)
- Up and down converter integration providing a wideband L-Band interface (or fiber optic)
- Easily accessible test and monitor points
- Strategically placed handles and storage to allow easy and safe access to hub
- Electric hoist on elevation platform for maintenance of hub RF electronics and drive components
- Elevation Maintenance Strut allowing maintenance of the EL actuator while maintaining service
- Lightning protection
- Redundant HVAC systems for hub and pedestal (pedestal is HVAC is optional)
- Hub and antenna mounted electrical outlets & lighting

OPTIONS:

- Power meter sensing of TX power capability
- Transmit signal block down converters allowing L-Band spectrum monitoring at control room
- Gas or electric (non-embedded heaters) anti-icing system for main reflector, subreflector & feed assembly
- Hub mounted test loop translator capability for station calibration with couplers
- IOT and CSM capabilities with precision calibrated couplers
- M&C System for monitoring and control of all hub components and RF (optional)
- Temperature monitoring

APPLICATIONS:

- Broadband Gateways (VHTS and HTS); TT&C; IOT; High Power Uplinks

9.2m Ka, Q and V-Band Turning Head Antenna

Specifications

PERFORMANCE PARAMETER ⁽¹⁾		KaTx/Q/Rx/VTx-Bands
Reflector		9.2 meter, counterweight
Optics Configuration		Cassegrain
Frequency	Transmit - V Band	47.2 - 52.4 GHz
	Transmit - Ka Band	27.5 - 30.0 GHz
Receive-Q Band Tracking (Monopulse)		37.5 - 42.5 GHz 37.5 - 42.5 GHz (any 2 GHz of RX Band)
Antenna Gain		
Transmit @ Feed Tx Port Input (V-Band)		70.1 dBi @ 47.20 GHz 70.8 dBi @ 52.40 GHz
Transmit @ Feed Tx Port Input (Ka-Band)		65.7 dBi @ 27.50 GHz 66.6 dBi @ 30.00 GHz
Receive @ Feed Rx Port Output		68.9 dBi @ 37.50 GHz 69.8 dBi @ 42.50 GHz
G/T (min) @ 30° Elevation, 230K LNA Clear Sky, Primary Path		43.0 dBi/K @ 42.00 GHz
EIRP with 250W Peak TWTA @V-Band Linear EIRP @ 4 dB OBO (19 dB NPR)		85.6 dBW @ 47.2GHz 86.3 dBW @ 52.4 GHz
EIRP with 550W Peak TWTA @Ka-Band Linear EIRP @ 4 dB OBO (19 dB NPR)		87.4 dBW @ 27.5 GHz 88.3 dBW @ 30.0 GHz
Polarization (Transmit and Receive) 3 dB Beamwidth		Dual Circular (RHCP/LHCP)
Transmit		0.04° Typical @ 49.80 GHz; 0.06° Typical @ 28.50 GHz
Receive		0.05° @ 39.75 GHz
Axial Ratio @ 1dB BW (X-POL Isolation, dB)		
Transmit		≤0.50 dB (≥30.7 dB)
Receive		≤0.50 dB (≥30.7 dB)
Port to Port Isolation		
Transmit to Receive		85 dB
Receive to Transmit		85 dB
Transmit to Transmit		18 dB
Receive to Receive		18 dB
VSWR/Return Loss		
Transmit		1.30:1/17.7 dB
Receive		1.30:1/17.7 dB
Sidelobe Performance		ITU-RS.580-6 (10% rule) FCC CFR-47 & 25.209
Power Handling		500 W CW ka-Gand, 100W V-Band CW per each TX port
Feed Waveguide Interface		
Transmit		WR-19 (V-Band), WR-34 (Ka-Band)
Receive		WR-22

⁽¹⁾ Some specifications may vary based on the combination of equipment, options and/or upgrades ordered.

9.2m Ka, Q and V-Band Turning Head Antenna

Specifications

PERFORMANCE PARAMETER ⁽¹⁾		KaTx/Q/Rx/VTx-Bands
Pressurization	Operational Maximum	0.25 psi 2.0 psi
Elevation Travel		0 to 90° continuous
Azimuth Travel		±100° continuous
AZ/EL Axis Velocity		0.5 °/s (AZ); 0.2 °/s (EL)
AZ/EL Axis Acceleration		0.2 °/s ²
Azimuth Drive Configuration		Single motor with dual gear and pinion drives with mechanical anti-backlash mechanism
Elevation Drive Configuration		Single motor machine jackscrew drive
Motor Type for Azimuth and Elevation		Brushless servo motor
Antenna Two-Axis Pointing Performance (over 10 degree of axis travel)		0.005° RMS, No wind 0.02° RMS winds 30 mph gusting to 45 mph
Tracking Performance for Optrack (C/No: 45 dB-Hz)		0.004° RMS, No wind 0.008° RMS winds 30 mph gusting to 45 mph
Tracking Performance for Monopulse (C/No: 45 dB-Hz)		0.003° RMS, No wind 0.005° RMS winds 30 mph gusting to 45 mph
Tracking Modes		Monopulse Program Track Optrack Step Track
Deicing		Feed Blower Heated Subreflector Optional Primary Reflector – Gas or Electric (as required)

⁽¹⁾ Some specifications may vary based on the combination of equipment, options and/or upgrades ordered.



9.2m KaQ/V-Band Antenna

9.2m Ka, Q and V-Band Turning Head Antenna

Specifications

ENVIROMENTAL PARAMETER ⁽¹⁾		KaTx/Q/Rx/VTx-Bands
Normal Conditions	Temperature	-22 to +122°F (-30 to +50°C, +55°C Optional)
	Wind	30 gusting to 45 mph (48 gusting to 72 km/hr)
	Humidity	30 to 100%, with condensation
	Rain	Up to 4 in/hr (100 mm/hr)
	Altitude	To 3280ft AMSL (1000m AMSL)
	Solar Radiation	1.1 kW/m ²
Degraded Conditions	Wind	45 gusting to 60 mph (72 gusting to 97 km/hr)
Limit of Driving	Wind	60 gusting to 75 mph (97 gusting to 120 km/hr)
Survival Conditions	Temperature	-40 to +131°F (-40 to +55°C)
	Wind	125 mph (200 km/hr) Continuous at zenith stow position
	Humidity	30 to 100%, with condensation
	Altitude	To 3280 ft AMSL (1000m AMSL)
	Seismic	0.3g horizontal & 0.15g vertical acceleration
Design Life		20 years

⁽¹⁾ Some specifications may vary based on the combination of equipment, options and/or upgrades ordered.



Contact us at CustomerCareSAT@cpii.com or call us at +1 770-689-2040

The data should be used for basic information only.

Formal, controlled specifications may be obtained from CPI for use in equipment design.



Antenna Technologies
2205 Fortune Drive
San Jose, CA
USA 95131

+1 770-689-2040
1 888-874-7646
(In North America)
1 619-240-8480
(Outside North America)
CustomerCareSAT@cpii.com
www.cpii.com

For more detailed information, please refer to the corresponding CPI technical description if one has been published, or contact CPI. Specifications may change without notice as a result of additional data or product refinement. Please contact CPI before using this information for system design. © 2022 Communications & Power Industries LLC. Company proprietary; use and reproduction is strictly prohibited without written authorization from CPI.

©2022 Communications & Power Industries LLC. Company proprietary; use and reproduction is strictly prohibited without written authorization from CPI.