Communications & Power Industries Triode





The 3CX2500D3 is a forced air cooled, ceramic/metal, medium-mu power triode designed primarily for use in industrial radio frequency heating services. Input of 7.77 kW is permissible up to 110 MHz. Plentiful reserve emission is available from it's 233 watt filament. The grid structure is rated at 75 watts making this tube an excellent choice for industrial service.

FEATURES:

Maximum plate dissipation: 2,500 Watts

Maximum screen dissipation:

Maximum grid dissipation: 75 Watts Frequency for max rating (CW): 110 MHz

Amplification factor: 24

Filament/cathode: **Thoriated Tungsten**

> Voltage: 7.5 Volts Current: 31.0 Amps

Capacitance: Grounded cathode

Input: 20.0 pF Output: 0.89 pF Feedthrough: 9.0 pF

Capacitance: Grounded grid

Input: --- pF Output: --- pF Feedthrough: --- pF Forced Air Cooling:

3-Pin Special Air Socket: Air Chimney:

Boiler:

Length: 7.6 in; 19.3 cm 4.125 in; 10.48 cm Diameter:

Weight: 4.0 lb; 8.8 kg

BENEFITS:

Base:

- Worldwide brand name recognition
- Over 85 years technical expertise

APPLICATIONS:

- Communications
- Industrial



		MAXIMUI	M RATINGS	TYPICAL OPERATION				
Class of Operation	Type of Service	Plate Voltage (Volts)	Plate Current (Amps)	Plate Voltage (Volts)	Screen Voltage (Volts)	Plate Current (Amps)	Drive Power (Watts)	Output Power (kiloWatts)
С	RF Industrial oscillator or amplifier	7,000	1.5	6,000		1.21	165	5.27

With a history of producing high quality products, we can help you with your triode.

Contact us at MPPMarketing@cpii.com or call us at +1 650-846-2800. The data should be used for basic information only.

Formal, controlled specifications may be obtained from CPI for use in equipment design.



Microwave Power Products Division 811 Hansen Way Palo Alto, California USA 94304 tel +1 650-846-2800 fax +1 650-856-0705 email MPPMarketing@cpii.com web www.cpii.com/MPP For more detailed information, please refer to the corresponding CPI technical description if one has been published, or contact CPI. Specifications may change without notice as a result of additional data or product refinement. Please contact CPI before using this information for system design.

©2020 Communications & Power Industries LLC. Company proprietary: use and reproduction is strictly prohibited without written authorization from CPI.