

Using technology developed for ModuMAX™ amplifiers, this rack-mount SSPA offers an output power of 350 watts across the standard 7.90-8.40 GHz satellite uplink band

The SSPA incorporates a modular architecture that includes the RF modules, power supplies, logic, fans, and front panel assembly. The amplifier is designed for reliable service in fixed and mobile applications.

#### FEATURES:

- 350 W saturated output power
- Digital gain adjustment (20 dB range)
- Forward and reflected power monitoring
- Microprocessor based monitor and control
- Serial interface (RS-232/-422/-485) standard
- 10 Base-T network interface (SNMP, HTTP)
- RF input and output sample port
- Integral 1:1 redundancy control


#### APPLICATIONS:

- Single-thread SSPA
- Redundant systems (1:1, 1:2)
- Fixed installations
- Mobile terminals
- Government and Military systems

#### ACCESSORIES:

- RCP-2001 remote panel


#### Block Diagram



Parameter	Notes	Specification
<b>Frequency Range</b>		7.90 to 8.40 GHz
<b>Gain, at Maximum Setting</b>		67 dB min., Standard
<b>Gain Adjustment Range</b>	Digital	20 dB min. in 0.1 dB steps
<b>Gain Flatness</b>		±1.0 dB over the full band; ±0.3 dB over any 40 MHz
<b>Saturated Power Output</b>		+55.5 dBm typ. (358 W)
<b>Power Output at 1dB compression (P<sub>1 dB</sub>)</b>		+54.8 dBm min. (305 W)
<b>Two Tone Intermodulation</b>		-25 dBc max., -30 dBc typical at 3 dB total backoff from 1dB compression point
<b>Group Delay</b>	Linear Parabolic Ripple	0.03 ns/MHz 0.003 ns/MHz <sup>2</sup> 1.0 ns peak to peak
<b>AM/PM Conversion</b>		2.5°/dB typical, 3.5°/dB max.at (P <sub>1 dB</sub> )
<b>VSWR</b>	Input Output	1.25:1 max, 1.30:1 typical 1.20:1 max, 1.30:1 typical
<b>RF Sample Ports</b>	Input Output	-10 dB typical -40 dB typical
<b>Connectors</b>	RF Input RF Output Sample Ports Serial I/O Parallel I/O System RCP Link Network Power	Type N Female CPR112G Waveguide Type N Female 9-pos D-sub Female, mate supplied 25-pos D-sub Male, mate supplied 15-pos D-sub Male, 9-pos D-sub, Male RJ-45 Jack 4-pos CE05, mate supplied
<b>Power Requirements</b>	Voltage Frequency Power Power factor corrected	90 to 135 VAC or 180 to 270 VAC 63 Hz max., 47 Hz min. 1900 W typical, 2100 W max. (1) .98 typical
<b>Cooling System</b>		Forced Air
<b>Operating Temperature Range</b>	Ambient air temperature	0°C to +50°C
<b>Dimensions</b>	See outline drawing	8.75" H x 19" W x 27.88" D; 222 mm H x 483 mm W x 708 mm D
<b>Weight</b>	Approximate	93 lb (42 kg)


(1) Cold start, at -40 °C and P<sub>OUT</sub> in saturation.

Outline Drawing, SSPA



Outline 18446

Outline Drawing, Typical 1:1 System



Outline 18833

**Connector Interface**

Ref. Des.	Function	Connector Type	Mating Connector	Comment
J1	RF Input	Type N Female	Type N Male	
J2	RF Output	CPR112G Waveguide	CPR112 Flange	
J3	AC In	4-pos CE05, Male	4-pos MS or CE05, Female	Mate supplied
J4	Serial I/O	9-pos D-sub, Female	9-pos D-sub, Male	Mate supplied
J5	Parallel I/O	25-pos D-sub, Male	25-pos D-sub, Female	Mate supplied
J6	RCP Link O	9-pos D-sub, Male	9-pos D-sub, Female	
J7	System	15-pos D-sub, Male	15-pos D-sub, Female	
J9	Network	RJ-45 Jack	RJ-45 Plug	
J10	Input Sample	Type N Female	Type N Male	Front panel mounted
J11	Output Sample	Type N Female	Type N Male	Front panel mounted

**Part Number Ordering Information**

<p><b>SSPA:</b>  <b>Part/Model No. DPXB8350R</b>                  7.90–8.40 GHz = B                  350 Watts = 350</p> <p>* Performance specifications of a redundant system depend on the installed configuration and optional accessories. Contact the factory for more information and for 1:2 system capabilities.</p>	<p><b>1:1 Redundant System*:</b>  <b>Part/Model No. DPRX1B350R-X</b>                  7.90–8.40 GHz = B                  350 Watts = 350</p> <p><b>Option:</b>  <b>Maintenance Switch.....A</b>                  Selects antenna or dummy load at system output</p>
--	---

**Related Accessory:**

**RCP-2001, SSPA Remote Control Panel**

1U-high rack-mount panel enables remote manual control of the SSPA. Can be located up to 1.3 km (4000 ft.) away and interconnects with inexpensive cable.



SMP Division  
 Satcom Products  
 tel: +1 (669) 275-2744  
 email: [satcommarketing@cpil.com](mailto:satcommarketing@cpil.com)  
 web: [www.cpii.com/satcom](http://www.cpii.com/satcom)

For more detailed information, please refer to the corresponding CPI technical description if one has been published, or contact CPI. Specifications may change without notice as a result of additional data or product refinement. Please contact CPI before using this information for system design.

© 2021 Communications & Power Industries LLC. Company proprietary; use and reproduction is strictly prohibited without written authorization from CPI.